

NOTICE D'INSTALLATION

Fixation adhésif double face : Coller le tracker avec l'adhésif double face sur une surface lisse : si votre ongle accroche légèrement ou beaucoup sur la surface, alors l'adhésif ne tiendra pas durablement. La colle atteint sa performance maximale 12h après la pose.

Acier/alu à moins de 50 cms entre la balise et le ciel ou hermétique

+50°C

-10 à 40°C

Positionnement Le plus haut possible

Spion l'après vol

The diagram illustrates the correct installation of the Spion tracker. It shows the tracker being placed on a smooth surface, with a warning against rough or textured surfaces. It specifies a temperature range of -10°C to 40°C for optimal performance, with a warning against temperatures above +50°C. It also shows the correct positioning on a motorcycle, with the tracker placed as high as possible on the rear section. A vertical bar indicates the correct height, with a green checkmark for the top section and a red thumbs-down for the bottom section. The logo 'Spion l'après vol' is also present.